



Model	Description	Price
PSN0101010A	Dell Chromebook 3100 Short Cable Battery Type 16DPH. Common part to touch, non-touch, and 2in1 devices. CBP BAT-SNG-8886-1 AG Parts: 16DPH MPN: 16DPH	\$ 43.74
PSN01010140	Dell Chromebook 3100 Long Cable Battery Type 51KD7. Common part to with touch, non-touch, and 2in1 devices. CBP: BAT-SNG-8886-1 AG Parts: FY8XM MPN: FY8XM	\$ 27.49
PSN01011001	Dell 3100 Chromebook LCD Top Cover for Touch and Non-Touch devices. CBP: BAC-SNG-9257-2 AG Parts: 34YFY MPN: 034YFY	\$ 28.74
PSN01011005	Dell Chromebook 3100 Bezel. Common part to Touch and Non Touch devices. CBP BEZ-SNG-7496-2 AG Parts 06C2J6 MPN 06C2J6	\$ 13.74
PSN01011007	Dell 3100 Bottom plate for Touch and Non-Touch CBP:BOT-SNG-6092-2 AG Part: 02RY30 MPN: 02RY30	\$ 22.49
PSN01011008	"Dell 11"" Chromebook 3100 Keyboard with power button, common part to 3100 Touch and Non-Touch. Also compatible with Dell 3110 Touch, Non-touch and 3120 Non-Touch devices. CBP KYB-SNG	\$ 18.74
PSN0101100D	Dell Chromebook 3100 Daughterboard. Common part to Touch and Non-touch Devices. Includes Cables. CBP: DAU-SNG-4962-1 AF Parts: G61M2 MPN : 0G61M2	\$ 16.24
PSN0101100E	Chromebook Dell 3100 Daughterboard, part common to Touch and Non-touch version Includes Cables CBP: DAU-SNG-4962-1 AF Parts: G61M2 MPN : 0G61M2	\$ 25.80
PSN01011010	Dell Chromebook 3100 Touchpad. Common part to Touch, Non-touch, and 2in1 devices. CBP: TPD-SNG-7201-3 AG Parts: RJR6J MPN: 0RJR6J	\$ 18.74
PSN01011011	Dell 11" Chromebook 3100 Hinge (Set), Common part to tch/non HNG-SET-8480-2	\$ 12.94
PSN01011013	Dell 11" Chromebook 3100 & 3110 & 3120 Speakers, part common to Touch, Non-touch, and 2in1 CBP: SPK-SET-3803-2 AG Parts: MFX68 MPN: 0MFX68	\$ 8.74
PSN01011014	Dell Chromebook 3100 Web-Camera. Common part to Touch, Non-touch, and 2in1 devices. AG Parts: G4JK9 MPN: 0G4JK9	\$ 9.99
PSN01011015	Dell 11" Chromebook 3100 & 3110 2in1 World Facing Camera. Compatible with 3100 2in1 WFC and Stylus device. AG Parts: XVRN2 MPN:XVRN2	\$ 19.99
PSN01011017	Dell Chromebook 3100 Short Battery Cable. Common part to Touch, Non-touch, and 2in1 devices. CBP: CBL-BAT-1956-2 AG Parts: 7PR30 MPN: 7PR30	\$ 8.74
PSN0101102F	Dell 11" Chromebook 3100 Bottom for Touch and Non-touch CBP:BOT-SNG-6092-2 AG Part: 02RY30 MPN: 02RY30	\$ 27.24
PSN01011033	Dell 11" Chromebook 3100 Bezel, Common part with Touch and Non Touch CBP BEZ-SNG-7496-2 AG Parts 06C2J6 MPN 06C2J6	\$ 16.43
PSN01011034	Dell 11" Chromebook 3100 Bottom for Touch and Non-touch CBP:BOT-SNG-6092-2 AG Part: 02RY30 MPN: 02RY30	\$ 27.24
PSN01011037	Dell 11" Chromebook 3100 Top for Touch and Non-touch devices. CBP: BAC-SNG-9257-2 AG Parts: 34YFY MPN: 034YFY	\$ 35.86
PSN0101103B	Dell 11" Chromebook 3100 Keyboard with power button. Common part to 3100 Touch and Non-touch. Also for the 3110 Touch and Non Touch. CBP KYB-SNG-6044-2 AG Parts: 0D2DT MPN: 00D2DT	\$ 25.80
PSN0101103F	Dell Chromebook 3100 Long Battery Cable. Common part to touch, non-touch, and 2in1 devices. AG Parts: 9MJG6 MPN: 09MJG6	\$ 8.74
PSN01011041	Chromebook Dell 3100 Daughterboard, part common to Touch and Non-touch version Includes Cables CBP: DAU-SNG-4962-1 AF Parts: G61M2 MPN : 0G61M2	\$ 25.80
PSN01011042	Dell Chromebook 3100 Left Hinge. Common part to Touch and Non-touch devices. CBP: HNG-SET-8480-2 AG Parts: R5KHK MPN: 0R5KHK	\$ 9.99
PSN01011043	Dell Chromebook 3100 Right Hinge. Common part to Touch and Non-touch devices. CBP: HNG-SET-8480-2 AG Parts: 8PKK7 MPN: 8PKK7	\$ 9.99
PSN01012000	Dell 11" Chromebook 3100 Touch laptop - use as replacement	\$ 375.00
PSN01012102	11" Touch LCD Screen, compatible with Dell Chromebook Models 3100 Touch, 3110 Touch. HP model G5EE Touch. CBP: LCD-SNG-9494-5 AG Parts: 2G5VN MPN: 02G5VN, NT116WHM-T00	\$ 62.49
PSN01012106	Dell 3100 Palmrest with Daughteboard ports. No Keyboard or Touchpad included. CBP: PLM-ASY-331-1 AG Parts: TK87M MPN: 0TK87M	\$ 28.74
PSN01012109	Dell Chromebook 3100 Touch Motherboard CBP: MOT-SNG-9454-2 AG Parts: DELL-3100T-4GB-MB MPN: 0W1C7C	\$ 96.19
PSN01012116	Dell Chromebook 3100 Touch LCD Cable CBP: CBL-LCD-3713-1 AG Parts: TWY13 MPN: 0TWY13	\$ 7.49
PSN01012135	11" Touch LCD Screen, compatible with Dell Chromebook Models 3100 Touch, 3110 Touch. HP model G5EE Touch. CBP: LCD-SNG-9494-5 AG Parts: 2G5VN MPN: 02G5VN, NT116WHM-T00	\$ -
PSN01012136	Dell 11" Chromebook 3100 Palmrest with Daughteboard ports. No Keyboard or Touchpad included. CBP: PLM-ASY-331-1 AG Parts: TK87M MPN: 0TK87M	\$ 35.86
PSN0101213C	Whole units used for Break Down.	\$ -
PSN0101300	Dell 11" 3100 Non-Touch Laptop - use as replacement	\$ 375.00
PSN01013102	11" Non-Touch LCD screen, compatible with Dell Chromebook Models 3100 Non-Touch, 3110 Non-Touch, 3120 Non-touch, 3180 Non-Touch, HP Chromebook Models G4 Non-Touch, G4EE Non-Touch	\$ 26.24
PSN01013106	Dell Chromebook 3100 Non-Touch Palmrest without Daughterboard ports. No Keyboard or Touchpad included. CBP: PLM-ASY-6106-1 AG Parts: 9X8D7 MPN: 09X8D7	\$ 29.99
PSN01013109	Dell Chromebook 3100 Motherboard Non-touch without Daughterboard Ports. CBP: MOT-SNG-9823-1 AG Parts: GD6HC MPN: 0N983V, 0VMPYY	\$ 137.49
PSN01013116	Dell Chromebook 3100 LCD Cable Non-touch. CBP:CBL-LCD-8703-1 AG Parts: V11RY MPN: 0V11RY	\$ 7.49
PSN0101312A	Dell Chromebook 3100 Motherboard Non-touch with Daughterboard Ports. CBP: MOT-SNG-9454-1 AG Parts: 1Y3PF MPN: 01Y3PF	\$ 137.49
PSN01013136	Dell 11" Chromebook 3100 Palmrest without Daughterboard ports. No Keyboard or Touchpad included. CBP: PLM-ASY-6106-1 AG Parts: 9X8D7 MPN: 09X8D7	\$ 35.86
PSN0101313C	Whole units used for Break Down.	\$ -
PSN0101335	11" Non-Touch LCD screen, compatible with Dell Chromebook Models 3100 Non-Touch, 3110 Non-Touch, 3120 Non-touch, 3180 Non-Touch, HP Chromebook Models G4 Non-Touch, G4EE Non-Touch	\$ -
PSN01014001	Dell Chromebook 3100 2in1 Top plate For Non-Stylus device CBP: BAC-SNG-9257-2 Ag parts: 279W8 MPN: 0279W8	\$ 22.49
PSN01014007	Dell Chromebook 3100 2in1 Bottom Plate Generic. Shared by all Dell 3100 2in1 models. CBP: BOT-SNG-6092-2 AG Parts: PPWP2 MPN: 0PPWP2	\$ 18.74

PSN01014008	Dell 11" Chromebook 3100 2in1 & 3110 2in1 & 3120 2in1 Keyboard with Lock Button CBP: KYB-SNG-6044-2 AG Parts: H06WJ MPN: 0H06WJ	\$ 18.74
PSN0101400D	Dell Chromebook 3100 2in1 Daughterboard Generic. Shared By all Dell 3100 2in1 Models. CBP: DAU-SNG-9926-1 AG Parts: RJ2NM MPN: RJ2NM	\$ 16.24
PSN0101400F	Dell Chromebook 3100 2in1 Sensor Board Generic CBP:DAU-SNG-8873-1 AG Parts: LS-G852P MPN: LS-G852P	\$ 7.49
PSN01014016	Dell Chromebook 3100 2in1 LCD Cable for Regular and WFC devices. CBP: CBL-LCD-5199-1 AG Parts: TWY13 MPN: 0TWY13	\$ 9.99
PSN0101401A	Dell Chromebook 3100 2in1 Sensor Board Cable for Non-Stylus devices. CBP: CBL-SNG-1571-1 AG Parts: YMTM3 MPN: 0YMTM3	\$ 8.74
PSN01014042	Dell Chromebook 3100 2in1 and 3110 2in1 Left Hinge CBP: HNG-SET-9837 AG Parts: R5KMT MPN: R5KMT	\$ 13.74
PSN01014043	Dell Chromebook 3100 2in1 & 3110 2in1 Right Hinge. CBP: HNG-SET-9837 AG Parts: YNRFG MPN: YNRFG	\$ 13.74
PSN01014103	Dell Chromebook 3100 2in1 LCD Panel without EMR Shield. CBP: LCD-MOD-3775-1 AG Parts: 45GHC MPN : 045GHC	\$ 112.49
PSN01014106	Dell Chromebook 3100 2in1 Palmrest without World Facing Camera port. CBP: PLM-ASY-931-1 AG Parts: 34Y6Y MPN: 034Y6Y	\$ 29.99
PSN01014109	Dell Chromebook 3100 2in1 Motherboard without World Facing Camera Port CBP: MOT-SNG-3766-1 AG Parts: R2K1H MPN: 0R2K1H	\$ 137.49
PSN01014131	Dell 11" Chromebook 3100 2in1 without world facing Camera CBP: PLM-ASY-931-1 AG Parts: 34Y6Y MPN: 034Y6Y	\$ 64.61
PSN01015106	Dell Chromebook 3100 2in1 Palmrest with World Facing Camera port. CBP: PLM-ASY-4135-1 AG Parts: WFYT5 MPN: 0WFYT5	\$ 29.99
PSN01015109	Dell Chromebook 3100 2in1 Motherboard with World Facing Camera. CBP: MOT-SNG-2054-1 AG Parts: FNMF1 MPN: 0FNMF1	\$ 162.49
PSN01016101	Dell Chromebook 3100 2in1 Top for Stylus Device. AG Parts: 5RY17 MPN : 05RY17	\$ 22.49
PSN01016103	Dell Chromebook 3100 2in1 LCD Panel with EMR Shield. CBP: LCD-MOD-2296-1 AG Parts: FHMWH MPN: FHMWH	\$ 162.49
PSN01016109	Dell Chromebook 3100 2in1 Motherboard with EMR port. CBP: MOT-SNG-2653-1 AG Parts: 0GC35 MPN: 00GC35	\$ 162.49
PSN01016116	Dell Chromebook 3100 2in1 LCD Cable for Stylus Device. AG Parts: YF2C0 MPN: YF2C0	\$ 9.99
PSN01016146	Dell Chromebook 3100 2in1 Stylus EMR Cable MPN: 0C7D1T	\$ 8.74
PSN01022101	Dell 11" ChromeBook 3120 Top Plate P/N #3CP5R	\$ 64.63
PSN01022106	Dell 11" Chromebook 3120 PalmRest P/N# R36YR	\$ 71.50
PSN01022107	PSN 3120 Bottom	\$ 13.73
PSN01022109	Dell 11" Chromebook 3120 Motherboard P/N# VDHYH	\$ 133.75
PSN0102210A	PSN 3120 Battery	\$ 74.24
PSN01022110	PSN 3120 Touchpad	\$ 34.36
PSN01022112	Dell Chromebook 3120 Wifi Card P/N# GPFNK	\$ 27.50
PSN01022113	Dell 11" Chromebook 3120 Speakers P/N# 5MXYN	\$ 20.63
PSN01022114	Dell ChromeBook 3120 Camera P/N# 0F9KGF	\$ 33.00
PSN01022116	PSN 3120 LCD cable	\$ 13.74
PSN01022118	Dell 11" 3120 Chromebook DC Jack P/N# 9F21D	\$ 24.75
PSN01031006	Dell 11" Chromebook 3180 (X-Generic) PalmRest CBP: PLM-ASY-9441-1	\$ 64.69
PSN01031007	Dell 11" Chromebook 3180 (X-Generic) Bottom CBP: BOT-SNG-6632-1	\$ 43.10
PSN01031008	Dell 11" Chromebook 3180 (X-Generic) Keyboard CBP: KYB-SNG-7584-2	\$ 50.24
PSN01031009	Dell 11" Chromebook 3180 (X-Generic) Motherboard CBP: MOT-SNG-5946-1	\$ 207.11
PSN01031010	Dell 11" Chromebook 3180 (X-Generic) Touchpad CBP: TPD-SNG-3412-1	\$ 43.10
PSN01031013	Dell 11" Chromebook 3180 (X-Generic) Speakers CBP: SPK-SET-6487-1	\$ 17.25
PSN01031018	Dell Chromebook 3180 (X-Generic) DC Jack, same part on 3189 CBP: DCJ-SNG-1894-1	\$ 14.35
PSN01031020	Dell 11" Chromebook 3180 (X-Generic) Hinge Cap (set) CBP: TRM-SET-6612-1	\$ 17.25
PSN0103111F	65w Dell Charger	\$ 50.29
PSN01032101	Dell 11" Chromebook 3180 Touch Backplate CBP: BAC-SNG-6484-1	\$ 43.10
PSN01032102	Dell 11" Chromebook 3180 Touch LCD, Common part to touch 3120/G6EE/G8EE CBP: LCD-SNG-199-1	\$ 142.31
PSN01032104	Dell 11" Chromebook 3180 Touch Backplate CBP: BAC-SNG-6484-1	\$ 21.88
PSN01032105	Dell 11" Chromebook 3180 Touch Bezel CBP: BEZ-SNG-6280-1	\$ 34.50
PSN01032111	Dell 11" Chromebook 3180 Touch Hinge (set) HNG-SET-6235-1	\$ 11.50
PSN01032116	Dell 11" Chromebook 3180 Touch LCD Cable CBP: CBL-LCD-7500-1	\$ 17.25
PSN01033101	Dell 11" Chromebook 3180 non-touch Top-Plate CBP: BAC-SNG-6622-1	\$ 43.10
PSN01033105	Dell 11" Chromebook 3180 non-touch Bezel CBP: BEZ-SNG-2274-1	\$ 43.10
PSN01033111	Dell 11" Chromebook 3180 non-tch Hinge (set) CBP: HNG-SET-4826-1	\$ 14.35
PSN01033116	Dell 11" Chromebook 3180 non-tch LCD Cable CBP: CBL-LCD-7500-1	\$ 28.73
PSN01051101	Dell 11" Chromebook 3189 Top Plate CBP: BAC-SNG-4398-1	\$ -
PSN01051103	Dell 11" Chromebook 3189 LCD panel CBP: 4WT7Y	\$ 40.25
PSN01051104	Dell 11" Chromebook 3189 HUD ???	\$ -
PSN01051106	Dell 11" Chromebook 3189 Palmrest CBP: PLM-ASY-2500-1	\$ 94.88
PSN01051107	Dell 11" Chromebook 3189 Bottom Plate CBP: BOT-SNG-5347-1	\$ 60.38
PSN01051108	Dell 11" Chromebook 3189 Keyboard CBP: KYB-SNG-1379-1	\$ 17.25
PSN01051109	Dell 11" Chromebook 3189 Motherboard CBP: MOT-SNG-4727-1	\$ 150.31

PSN0105110D	Dell 11" Chromebook 3189 Daughterboard (Pwr&Audio) CBP: DAU-SET-8314-1	\$ 86.25
PSN0105110E	Dell 11" Chromebook 3189 Dghtrbd (Audio only) CBP: DAU-SNG-8141-1	\$ -
PSN01051113	Dell 11" Chromebook 3189 Speakers ???	\$ -
PSN01051118	Dell 11" Chromebook 3189 DC Jack CBP: DCJ-SNG-1894-2	\$ -
PSN010A2101	Dell 11" Chromebook 5190 Top Plate	\$ 35.94
PSN010A2105	Dell 11" Chromebook 5190 Bezel	\$ 24.74
PSN010A2106	Dell 11" Chromebook 5190 Palmrest	\$ 64.69
PSN010A2107	Dell 11" Chromebook 5190 Bottom	\$ 35.94
PSN010A2109	Dell 11" Chromebook 5190 Motherboard	\$ 82.44
PSN010A210A	Dell 11" Chromebook 5190 Battery	\$ 50.31
PSN010A2116	PSN 5190 LCD cable	\$ 13.74
PSN010D0007	Dell Chromebook 3110 Bottom Plate Generic. MPN: 0KT6XH	\$ 14.99
PSN010D000A	Dell Chromebook 3110 Battery Generic Ag parts: 26JGK MPN: 026JGK	\$ 61.24
PSN010D0010	Dell Chromebook 3110 Touchpad. Common part to Touch, Non-touch, and 2in1 devices.	\$ 18.74
PSN010D0011	Dell 3110 Generic Chromebook Hinge Set	\$ 16.49
PSN010D0017	Dell 11" Chromebook 3110 Battery Cable Ag parts: 4VM0K MPN: 07T73H	\$ 8.19
PSN010D0034	Dell 11" Chromebook 3100 Bottom Grade C	\$ 38.74
PSN010D0042	Dell Chromebook 3110 Left Hinge Generic AG Parts: WPPDT MPN: WPPDT	\$ 9.99
PSN010D0043	Dell Chromebook 3110 Right Hinge Generic AG Parts: 1GPD6 MPN: 1GPD6	\$ 9.99
PSN010D1101	Dell Chromebook 3110 2in1 Top-Plate CBP: BAC-SNG-2017-1 AG Parts: YW3DH MPN: 0YW3DH	\$ 26.24
PSN010D1103	Dell Chromebook 3110 2in1 LCD with 30 pin connector. CBP: LCD-MOD-1307-1 AG Parts: KY8GR MPN: 0KY8GR	\$ 124.99
PSN010D1106	Dell 11" Chromebook 3110 2in1 Palmrest with WFC CBP: PLM-ASY-6585-1 AG Parts: P3NG2 MPN: 0P3NG2	\$ 34.28
PSN010D1107	Dell Chromebook 3110 2in1 Bottom Plate Generic MPN: 0KT6XH	\$ 18.74
PSN010D1109	Dell Chromebook 3110 2in1 Motherboard with World Facing Camera port. CBP: MOT-SNG-9152-1 AG Parts: 7HRRT MPN: 07HRRT	\$ 249.99
PSN010D1116	Dell Chromebook Model 3110 2in1 LCD Cable 30 pin CBP: CBL-LCD-6760-1 AG Parts: Y21WR MPN: 0Y21WR	\$ 11.24
PSN010D112B	Dell Chromebook 3110 2in1 Palmrest with World Facing Camera port. MPN: CKY67	\$ 29.99
PSN010D2001	Dell Chromebook 3110 Top for device with HDMI Port MPN: 0PWN1F	\$ 26.24
PSN010D2005	Dell Chromebook 3110 Bezel for device with HDMI Port MPN: W5W31	\$ 17.49
PSN010D2014	Dell Chromebook 3110 Web Cam for device with HDMI port. MPN: 0XYXJ2	\$ 19.99
PSN010D2016	Dell Chromebook 3110 Touch LCD Cable MPN: 0RT4GY	\$ 19.99
PSN010D202B	Dell 3110 Palmrest with HDMI ports. No Keyboard or Touchpad included. MPN: 00H7CN	\$ 29.99
PSN010D2031	Dell 11" Chromebook 3110 Palmrest with HDMI Port Grade B	\$ 41.19
PSN010D2032	Dell 11" Chromebook 3110 Top for device with HDMI Port MPN: 0PWN1F	\$ 35.86
PSN010D2037	Dell 11" Chromebook 3110 Top for device with HDMI Port MPN: 0PWN1F	\$ 35.86
PSN010D203C	Whole units used for Break Down.	\$ -
PSN010D3001	Dell Chromebook Model 3110 Top for device without HDMI Port MPN: 0T45KM	\$ 26.24
PSN010D3005	Dell Chromebook 3110 Bezel for device without HDMI Port MPN: 0KJ49X	\$ 14.99
PSN010D3006	Dell Chromebook 3110 Palmrest without Daughterboard ports. No Keyboard or Touchpad included. MPN: 0WP30N	\$ 29.99
PSN010D3009	Dell Chromebook 3110 Motherboard without HDMI port MPN: V8TP1	\$ 212.49
PSN010D3014	' Dell Chromebook 3110 Web Cam for device without HDMI port. MPN: 0M05K0	\$ 16.24
PSN010D3016	Dell Chromebook 3110 Non Touch LCD Cable MPN: 05RT23	\$ 11.24
PSN010D302A	Dell Chromebook 3110 Motherboard with HDMI port. AG Parts: MPN5T MPN: MPN5T	\$ 224.99
PSN010D3031	Dell 11" Chromebook 3110 Palmrest without HDMI Port Grade B	\$ 29.99
PSN010D3037	Dell 11" Chromebook 3110 Top for device without HDMI Port MPN: 0T45KM	\$ 54.99
PSN010D303C	Whole units used for Break Down.	\$ -
PSN010F1001	3150 Top	\$ 20.56
PSN010F1005	' 3150 Bezel	\$ 54.94
PSN010F1006	' 3150 Palm	\$ 41.19
PSN010F1008	3150 Keyboard	\$ 28.88
PSN010F1009	3150 Motherboard	\$ 32.99
PSN010F1012	3150 Wifi card	\$ 24.69
PSN010F1013	3150 Speaker	\$ 41.19
PSN010F1016	3150 LCD cable	\$ 13.69
PSN010F1017	3150 Battery Cable	\$ 20.56
PSN01101004	5300 HUD	\$ 75.00

PSN01101006	5300 Palm	\$ 32.94
PSN01101008	5300 Keyboard	\$ 54.94
PSN01101009	5300 Motherboard	\$ 274.94
PSN01101013	5300 Speakers	\$ 20.56
PSN01111008	5285 2in1 Travel Keyboard	\$ 137.44
PSN02061106	HP 11" Chromebook G3 Palmrest	\$ 63.24
PSN02071001	HP 11" Chromebook G4 (X-Generic) Top Plate CBP: BAT-SNG-447-2	\$ 35.94
PSN02071005	HP 11" Chromebook G4 (X-Generic) Bezel CBP: BEZ-SNG-422-3	\$ -
PSN02071007	HP 11" Chromebook G4 (X) Bottom-Plate CBP: BOT-SNG-238-2	\$ -
PSN02071009	HP 11" Chromebook G4 (X-Generic) Motherboard Common Part with G3,G4EE CBP: MOT-SNG-562-2	\$ -
PSN0207100A	HP 11" Chromebook G4 (X-Generic) Battery CBP: BAT-SNG-447-2	\$ -
PSN0207100D	HP 11" Chromebook G4 (X-Generic) Daughterboard/Cardreader THERE"S STILL A QUESTION OF MODEL/VERSION ON THIS, confirm validity of PN and if on Silver/Black version Leaving temporarily	\$ -
PSN02071010	HP 11" Chromebook G4 (X-Generic) Touchpad CBP: TPD-SNG-159-2	\$ -
PSN02071011	HP 11" Chromebook G4 (X-Generic) Hinge (set) CBP: HNG-SET-593-2	\$ -
PSN02071013	HP 11" Chromebook G4 (X-Generic) Speaker (set) CBP: SPK-SET-280-2	\$ -
PSN02071014	HP 11" Chromebook G4 (X-Generic) Web-Camera CBP: CAM-SNG-3219-2	\$ -
PSN02071016	HP 11" Chromebook G4 (X-Generic) LCD Cable CBP: CBL-LCD-227-2	\$ -
PSN02071018	HP 11" Chromebook G4 (X-Generic) DC Jack CBP: DCJ-SNG-300-2	\$ -
PSN0207101C	HP 11" Chromebook G4 Camwire	\$ 21.24
PSN02073106	HP 11" Chromebook G4 (Silver) Palmrest CBP: PLM-ASY-623-2	\$ 57.49
PSN02081105	HP 11" Chromebook G4EE Bezel CBP: BEZ-SNG-119-1	\$ 10.05
PSN02081106	HP 11" Chromebook G4EE Palmrest w/ Trackpad CBP: PLM-ASY-4307-1	\$ 76.99
PSN02081107	HP 11" Chromebook G4EE Bottom-Plate CBP: BOT-SNG-225-1	\$ 15.63
PSN02081109	HP 11" Chromebook G4EE Motherboard CBP: MOT-SNG-562-3	\$ 100.63
PSN02081110	HP 11" Chromebook G4EE Touchpad CBP: TPD-SNG-252-1	\$ -
PSN02081112	HP 11" Chromebook G4EE Wifi-card CBP: WIF-SNG-829-8	\$ -
PSN02091001	HP 11" Chromebook G5 (X-Generic) Top Plate BAC-SNG-334-1	\$ 41.25
PSN02091006	HP 11" Chromebook G5 (X-Generic) Palmrest (Silver) PLM-ASY-5898-1	\$ 68.75
PSN02091007	HP 11" Chromebook G5 (X-Generic) Bottom BOT-SNG-676-1	\$ 71.86
PSN02091009	HP 11" Chromebook G5 (X-Generic) Motherboard MOT-SNG-564-1	\$ 171.88
PSN0209100A	HP 11" Chromebook G5 (X-Generic) Battery BAT-SNG-5621-2	\$ 86.24
PSN0209100D	HP 11" Chromebook G5 (X-Generic) Daughter Board DAU-SNG-544-1	\$ 20.63
PSN02091010	HP 11" Chromebook G5 (X-Generic) Touchpad TPD-SNG-4222-1	\$ 28.74
PSN02093116	HP 11" Chromebook G5 Non-touch LCD Cable (CBP) CBL-LCD-2328-1	\$ 21.55
PSN020A1007	HP 11" Chromebook G5EE (X-Generic) Backplate (CBP) BOT-SNG-6559-1	\$ 41.25
PSN020A1009	HP 11" Chromebook G5EE (X-Generic) Motherboard MOT-SNG-9776-1	\$ 171.88
PSN020A100A	HP 11" Chromebook G5EE (X-Generic) Battery (CBP) BAT-SNG-6841-1	\$ 71.86
PSN020A100D	HP 11" Chromebook G5EE (X-Generic) Daughterboard (CBP) DAU-SNG-7488-1	\$ 20.63
PSN020B1014	HP 11" Chromebook G6EE (X-Generic) Web-Camera (CBP) CAM-SNG-4623-1	\$ 28.75
PSN020D1001	HP Chromebook G8EE Top Plate Generic CBP: BAC-SNG-7565-2 MPN: L89771-001	\$ 23.74
PSN020D1005	HP Chromebook G8EE & 11MK G9-EE Bezel Generic CBP: BEZ-SNG-8318-2 AG Parts: L89773-001 MPN: L89773-001	\$ 18.74
PSN020D1007	HP Chromebook G8EE Bottom Plate With SD slot CBP BOT-SNG-4589-2 AG Parts: L89764-001 MPN: L89764-001	\$ 23.74
PSN020D100A	HP Chromebook L75783-005 Battery. Compatible with G8, G9, 14" G6 and X360 G3. CBP: BAT-SNG-3239-6 AG Parts: L75783-005 MPN: L75783-005	\$ 27.49
PSN020D1010	HP Chromebook G8EE Touchpad Generic CBP: TPD-SNG-3737-4 AG Parts: L89789-001 MPN: L89789-001	\$ 18.74
PSN020D1011	HP 11" Chromebook G8EE non-touch (X-Generic) Hinge (Set) (CBP) HNG-SET-7554-2	\$ 15.05
PSN020D1013	HP Chromebook G8EE Speakers Generic CBP: SPK-SET-8207-2 AG Parts: L89788-001 MPN: L89788-001	\$ 4.99
PSN020D1014	HP Chromebook G8EE Web Camera CBP: CAM-SNG-8447-4 AG Parts: L51916-001 MPN: L51916-001	\$ 8.74
PSN020D101C	HP Chromebook G8EE Camera cable CBP: CBL-CAM-5137-1 AG Parts: DD0GAHCM010 MPN: DD0GAHCM010	\$ 9.99
PSN020D1021	HP Chromebook G8EE Hinge Cover Generic CBP: TRM-SNG-9225-1 AG Parts: L89769-001 MPN: L89769-001	\$ 9.99
PSN020D102E	HP 11" Chromebook G8EE & G9EE Bezel CBP: BEZ-SNG-8318-2 AG Parts: L89773-001 MPN: L89773-001	\$ 26.05
PSN020D102F	HP 11"G8EE Bottom with SD slot CBP BOT-SNG-4589-2 AG Parts: L89764-001 MPN: L89764-001	\$ 57.49
PSN020D1032	HP 11" Chromebook G8EE Top CBP: BAC-SNG-7565-2 MPN: L89771-001	\$ 26.05
PSN020D1033	HP 11" Chromebook G8EE & G9EE Bezel CBP: BEZ-SNG-8318-2 AG Parts: L89773-001 MPN: L89773-001	\$ 26.05
PSN020D1034	HP 11"G8EE Bottom Plate With SD slot CBP BOT-SNG-4589-2 AG Parts: L89764-001 MPN: L89764-001	\$ 57.49
PSN020D1037	HP 11" Chromebook G8EE Top CBP: BAC-SNG-7565-2 MPN: L89771-001	\$ 26.05

PSN020D1042	HP Chromebook G8EE Left Hinge AG Parts: L89768-001 MPN: L89768-001	\$ 4.99
PSN020D1043	HP Chromebook G8EE Right Hinge AG Parts: L89768-001 MPN: L89768-001	\$ 4.99
PSN020D1044	HP Chromebook HP G8EE & 11MK G9EE Hinge Crossbar MPN: L89774-001	\$ 4.99
PSN020D3106	HP Chromebook G8EE Intel Palmrest CBP: PLM-SNG-1453-1 MPN: L82760-001	\$ 36.24
PSN020D3109	HP 11" Chromebook G8EE Intel Motherboard CBP: MOT-SNG-1404-1 AG Parts: L89778-001 MPN: L89778-001	\$ 90.69
PSN020D310D	HP 11" Chromebook G8EE Intel Daughterboard Revision A CBP: DAU-SNG-8834-1 AG Parts: L89792-001 MPN: L89792-001	\$ 14.36
PSN020D310E	HP 11" Chromebook G8EE Intel Daughterboard Revision B CBP: DAU-SNG-8834-1 AG Parts: L89792-001-REV:B MPN: L89792-001	\$ 14.36
PSN020D3112	HP Chromebook G8EE Wifi Card. Compatible with G6EE, G8EE. & 14A G5 CBP: WIF-SNG-6937-4 AG Part: L54597-001 MPN: L54597-001	\$ 4.99
PSN020D3116	HP Chromebook G8EE & 11MK G9EE LCD Cable Non-touch. CBP: CBL-LCD-9455-1 AG Parts: DD0GAHLC120 MPN: DD0GAHLC120	\$ 12.49
PSN020D3141	HP 11" Chromebook G8EE Intel Daughter Board Revision C CBP: DAU-SNG-8834-1	\$ 14.36
PSN020D5206	HP Chromebook G8EE AMD Palmrest CBP: PLM-ASY-9627-1 AG Parts: L90338-001 MPN: L90338-001	\$ 32.49
PSN020D5209	HP Chromebook G8EE AMD Motherboard CBP: MOT-SNG-6184-1 AG Parts: L92813-001 MPN: L92813-001	\$ 124.99
PSN020D5231	HP 11" Chromebook G8EE AMD Palmrest Grade B CBP: PLM-ASY-9627-1	\$ 59.05
PSN020D5236	HP 11" Chromebook G8EE AMD Palmrest Grade C CBP: PLM-ASY-9627-1	\$ 59.05
PSN020D523D	Whole units used for Break Down.	\$ -
PSN020D520D	HP Chromebook G8EE AMD Daughterboard CBP: DAU-SNG-3258-1 AG Parts: L92816-001 MPN: L92816-001	\$ 14.99
PSN020E4301	HP 11" Chromebook 11MK G9EE Top Generic CBP: BAC-SNG-5018-1 AG Parts: M44249-001 MPN: M44249-001	\$ 28.74
PSN020E4306	HP Chromebook 11MK G9EE Palmrest Generic CBP: PLM-ASY-9738-1 AG Parts: M44258-001 MPN: M44258-001	\$ 42.49
PSN020E4307	HP Chromebook 11MK G9EE Bottom Generic CBP: BOT-SNG-3293-1 AG Parts: M44242-001 MPN: M44242-001	\$ 19.99
PSN020E4309	HP Chromebook 11MK G9EE Motherboard CBP: MOT-SNG-5708 AG Parts: M44238-001 MPN: M44238-001	\$ 199.99
PSN020E430D	HP Chromebook 11MK G9EE Hall Sensor Board CBP: DAU-SNG-3082-1 AG Parts: M44240-001 MPN: M44240-001	\$ 13.74
PSN020E4310	HP Chromebook 11MK G9EE Touchpad CBP: TPD-SNG-5586-1 AG Parts: M44244-001 MPN: M44244-001	\$ 18.74
PSN020E4311	HP 11" Chromebook G9EE non-touch MTK Hinge Set HNG-SET-7402-1	\$ 14.36
PSN020E4313	HP Chromebook 11MK G9EE Speakers CBP: SPK-SET-8207-3 AG Parts: M44246-001 MPN: M44246-001	\$ 4.99
PSN020E4314	HP Chromebook 11MK G9EE Web Camera CBP: CAM-SNG-3460-1 AG Parts: M44253-001 MPN: M44253-001	\$ 18.74
PSN020E431C	HP Chromebook 11MK G9EE Camera Cable CBP: CBL-CAM-4978-1 AG Parts: DD0GMACM011 MPN: DD0GMACM011	\$ 7.49
PSN020E4321	HP Chromebook 11MK G9EE Hinge Cover CBP: TRM-SNG-3303-1 AG Parts: M44252-001 MPN: M44252-001	\$ 11.24
PSN020E4337	HP 11" Chromebook G9EE Top CBP: BAC-SNG-5018-1 AG Parts: M44249-001 MPN: M44249-001	\$ 43.05
PSN020E4342	HP Chromebook 11MK G9EE Left Hinge CBP: HNG-SET-7402-1 AG Parts: M44251-001 MPN: M44251-001	\$ 7.49
PSN020E4343	HP Chromebook 11MK G9EE Right Hinge CBP: HNG-SET-7402-1 AG Parts: M44251-001 MPN: M44251-001	\$ 7.49
PSN020F1202	HP Chromebook 14" DB LCD LCD-SNG-1568-2	\$ 79.74
PSN020F1206	HP Chromebook 14" DB Palmrest CBP: PLM-ASY-7270-1	\$ 136.11
PSN02101105	HP Chromebook 14" G4 non-touch Bezel ???	\$ 54.99
PSN02101106	HP Chromebook 14" G4 non-touch Palmrest CBP: PLM-ASY-212-2	\$ 187.49
PSN02101109	CB 14" G4 n-tch Motherboard CBP: MOT-SNG-583-1	\$ 172.49
PSN02111005	HP Chromebook 14" G5 (X-Generic) Bezel (CBP) BEZ-SNG-8545-2	\$ 43.11
PSN02111209	HP Chromebook 14" G5 (AMD) non-touch Motherboard (CBP) MOT-SNG-2602-1	\$ 43.69
PSN03011101	Lenovo 11" Chromebook 100e Gen 1 Intel Top BAC-SNG-8716-1	\$ 41.61
PSN03011105	Lenovo 11" Chromebook 100e Gen 1 Bezel BEZ-SNG-537-1	\$ 27.24
PSN03011106	Lenovo Chromebook 100e Gen 1 Intel Palmrest PLM-ASY-2502-1	\$ 22.44
PSN03011107	Lenovo 11" Chromebook 100e Gen 1 Intel Bottom BOT-SNG-1251-1	\$ 14.30
PSN03011109	Lenovo 11" Chromebook 100e Gen 1 Intel Motherboard MOT-SNG-5552-1	\$ 157.43
PSN03021107	Lenovo 11" Chromebook 100e Gen 2 Intel Bottom BOT-SNG-1251-1	\$ 27.24
PSN0302110A	Lenovo Chromebook 100e Gen 2 Intel Battery BAT-SNG-7312-2	\$ 35.86
PSN0302110D	'Lenovo 11" Chromebook 100e Gen 2 Intel V1 Daughterboard This model has a US only version (V2) we don't stock, the differences are in motherboard and daughterboard only DAU-SNG-6015-1	\$ 66.05
PSN03021110	Lenovo 11" Chromebook 100e Gen 2 Intel Touchpad TPD-SNG-8363-3	\$ 15.10
PSN03021111	Lenovo 11" Chromebook 100e Gen 2 Intel Hinge Set CBP: HNG-SNG-8944-1	\$ 18.61
PSN03021112	Lenovo 11" Chromebook 100e Gen 2 Intel Wifi-card WIF-SNG-2121-3	\$ 12.93
PSN03021116	Lenovo Chromebook 100e Gen 2 Intel LCD Cable CBL-LCD-4569-2	\$ 21.49
PSN03023301	Lenovo 11" Chromebook 100e Gen 2 MTK Top BAC-SNG-650-1	\$ 14.94
PSN03023305	Lenovo 11" Chromebook 100e Gen 2 MTK Bezel BEZ-SNG-9984-1	\$ 50.30
PSN03023306	Lenovo 11" Chromebook 100e Gen 2 MTK V1 Palmrest not currently stocking V2 US only model PLM-ASY-5968-1	\$ 93.43
PSN03023307	Lenovo 11" Chromebook 100e Gen2 MTK v1 Bottom currently not stocking v2 versions BOT-SNG-1887-1	\$ 50.30
PSN03023309	Lenovo 11" Chromebook 100e G2 MTK (Ver 1) Motherboard Not stocking V2 version MOT-SNG-5718-1	\$ 222.80
PSN0302330A	Lenovo 11" Chromebook 100e G2 MTK Battery BAT-SNG-1431-1	\$ 71.86

PSN0302330D	Chromebook 11" 100e G2 MTK Daughterboard DAU-SNG-3590-1	\$ 14.36
PSN03023310	Lenovo 11" Chromebook 100e G2 MTK v1 Touchpad currently not stocking v2 versions TPD-SNG-8363-1	\$ 14.36
PSN03023311	Lenovo 11" Chromebook 100e G2 MTK v1 Hinge (set) currently not stocking v2 version HNG-SET-8856-1	\$ 43.11
PSN03023313	Lenovo 11" Chromebook 100e G2 MTK v1 Speakers currently not stocking v2 version SPK-SET-4409-1	\$ 7.18
PSN03023314	Lenovo 11" Chromebook 100e G2 MTK Camera CAM-SNG-2776-4	\$ 28.74
PSN03023316	Lenovo 11" Chromebook 100e G2 MTK LCD cable CBL-LCD-9973-1	\$ 28.74
PSN03041001	Lenovo 11" Chromebook 300e Gen 2 Top . Compatible with AST, MTK, and Intel models. CBP: BAC-SNG-2195-4 AG Parts: 5CB0T70713 MPN: 5CB0T70713	\$ 19.99
PSN03041003	Lenovo Chromebook 300e G2 11.6" Touch LCD with sensor board. Compatible with AST, MTK, and Intel models. CBP: LCD-MOD-9392-1 AG Parts: 5D10T95195 MPN: 5D10T95195	\$ 112.49
PSN03041014	Lenovo Chromebook 300e G2 Camera Generic. Web Cam for 300e G2 MTK, AST, and Intel devices. CBP: CAM-SNG-7949-1 AG Parts: 5C20T79479 MPN: 5C20T79479	\$ 13.74
PSN03041022	Lenovo Chromebook 300e G2 Spine Cover Generic. Compatible with Lenovo 300e G2 MTK, AST, and Intel devices. Also compatible with Lenovo 500e G2. Grade A CBP: TPD-SNG-8363-7 AG Parts:	\$ 7.49
PSN03041037	Lenovo 11" Chromebook 300e Gen 2 Top. Compatible with AST, MTK, and Intel models. CBP: BAC-SNG-2195-4 AG Parts: 5CB0T70713 MPN: 5CB0T70713	\$ 35.91
PSN0304211	Lenovo 11" Chromebook 300e Gen 2 AST Hinge (Set) HNG-SET-2569-2	\$ 22.93
PSN0304216	Lenovo Chromebook 300e G2 AST LCD Cable CBP: CBL-LCD-3918-1 AG Parts: 5C10T70712 MPN: 5C10T70712	\$ 9.99
PSN03042306	Lenovo Chromebook 300e G2 MTK Palmrest CBP: PLM-ASY-5377-1 AG parts: 5CB0T95165 MPN: 5CB0T95165	\$ 44.99
PSN03042307	Lenovo 11" Chromebook 300e Gen 2 MTK Bottom CBP: BOT-SNG-7181-1 AG Parts: 5CB0T95166 MPN: 5CB0T95166	\$ 16.24
PSN03042309	Lenovo Chromebook 300e G2 MTK Motherboard MOT-SNG-196-1	\$ 87.49
PSN0304230A	Lenovo 11" Chromebook 300e Gen 2 MTK Battery Grade A, Battery health is at 90% minimum. CBP: BAT-SNG-1431-2 AG Parts: 5B10T36867 MPN: 5B10T36867	\$ 41.24
PSN0304230D	Lenovo Chromebook 300e G2 MTK Daughterboard CBP: DAU-SNG-9140-1 AG Parts: 5C50T95169 MPN: 5C50T95169	\$ 17.49
PSN03042310	Lenovo Chromebook 300e G2 MTK Touchpad CBP: TPD-SNG-8363-2 AG Parts: ST50593092 MPN: ST50593092	\$ 17.49
PSN03042311	Lenovo 11" Chromebook 300e Gen 2 MTK Hinge (set) HNG-SET-4002-1	\$ 14.38
PSN03042313	'Lenovo Chromebook MTK speaker set, compatible with 100e G2 MTK, 300e G1 MTK, and 300e G2 MTK. CBP: SPK-SET-5045-1 AG Parts: 5SB0Q93988 MPN: 5SB0Q93988	\$ 12.49
PSN03042316	Lenovo Chromebook 300e G2 MTK LCD cable CBP: CBL-LCD-9518-1 AG Parts: 5C10T95191 MPN: 5C10T95191	\$ 14.99
PSN0304232F	Lenovo 11" Chromebook 300e Gen 2 MTK Bottom CBP: BOT-SNG-7181-1 AG Parts: 5CB0T95166 MPN: 5CB0T95166	\$ 35.94
PSN03042331	Lenovo 11" Chromebook 300e Gen 2 MTK Palmrest Grade B CBP: PLM-ASY-5377-1 AG parts: 5CB0T95165 MPN: 5CB0T95165	\$ 69.00
PSN03042334	Lenovo 11" Chromebook 300e Gen 2 MTK Bottom CBP: BOT-SNG-7181-1 AG Parts: 5CB0T95166 MPN: 5CB0T95166	\$ 35.94
PSN03042336	Lenovo 11" Chromebook 300e Gen 2 MTK Palmrest Grade C CBP: PLM-ASY-5377-1 AG parts: 5CB0T95165 MPN: 5CB0T95165	\$ 69.00
PSN0304233C	Whole units used for Break Down.	\$ -
PSN03042342	Lenovo Chromebook 300e G2 MTK Left Hinge CBP: HNG-SET-4002-1 AG Parts: 5H50T95189 MPN: 5H50T95189	\$ 8.75
PSN03042343	Lenovo Chromebook 300e G2 MTK Right Hinge CBP: HNG-SET-4002-1 AG parts: 5H50T95189 MPN: 5H50T95189	\$ 8.75
PSN03042347	Lenovo 11" Chromebook 300e Gen 2 MTK Battery Grade B, Battery health is at 80% minimum. CBP: BAT-SNG-1431-2 AG Parts: 5B10T36867 MPN: 5B10T36867	\$ 50.31
PSN03042349	Lenovo Chromebook 300e Gen 2 MTK Left Hinge CBP: HNG-SET-4002-1 AG Parts: 5H50T95189 MPN: 5H50T95189	\$ 11.65
PSN0304234A	Lenovo 11" Chromebook 300e Gen 2 MTK Right Hinge CBP: HNG-SET-4002-1 AG parts: 5H50T95189 MPN: 5H50T95189	\$ 11.65
PSN0304234B	Lenovo Chromebook 300e Gen 2 MTK Left Hinge CBP: HNG-SET-4002-1 AG Parts: 5H50T95189 MPN: 5H50T95189	\$ 11.65
PSN0304234C	Lenovo Chromebook 300e Geb 2 MTK Right Hinge CBP: HNG-SET-4002-1 AG parts: 5H50T95189 MPN: 5H50T95189	\$ 11.65
PSN0304242	Lenovo Chromebook 300e G2 AST Left Hinge CBP: HNG-SET-2569-2 AG Parts: 5H50T45066 MPN: 5H50T45066	\$ 8.75
PSN0304243	Lenovo Chromebook 300e G2 AST Right Hinge CBP: HNG-SET-2569-2 AG Parts: 5H50T45066 MPN: 5H50T45066	\$ 8.75
PSN0304249	Lenovo Chromebook 300e G2 AST Left Hinge CBP: HNG-SET-2569-2 AG Parts: 5H50T45066 MPN: 5H50T45066	\$ 11.66
PSN030424A	Lenovo Chromebook 300e Gen 2 AST Right Hinge CBP: HNG-SET-2569-2 AG Parts: 5H50T45066 MPN: 5H50T45066	\$ 11.66
PSN030424B	Lenovo Chromebook 300e Gen 2 AST Left Hinge CBP: HNG-SET-2569-2 AG Parts: 5H50T45066 MPN: 5H50T45066	\$ 11.66
PSN030424C	Lenovo Chromebook 300e Gen 2 AST Right Hinge CBP: HNG-SET-2569-2 AG Parts: 5H50T45066 MPN: 5H50T45066	\$ 11.66
PSN03043206	Lenovo Chromebook 300e Gen 2 AST Palmrest with World Facing Camera port. CBP: PLM-ASY-3531-1 AG Parts: 5CB0Z21553 MPN: 5CB0Z21553	\$ 37.49
PSN03043207	Lenovo 11" Chromebook 300e Gen 2 AST Bottom CBP: BOT-SNG-5561-1 AG Parts: 5CB0Y97711 MPN: 5CB0Y97711	\$ 16.24
PSN03043209	Lenovo Chromebook 300e G2 AST Motherboard with World Facing Camera port CBP: MOT-SNG-9723-1 AG Parts: 5B21B63141 MPN: 5B21B63141	\$ 162.49
PSN0304320A	Lenovo Chromebook 300e G2 AST Battery CBP: BAT-SNG-6147-2 AG Parts: 5B10X65680 MPN: 5B10X65680	\$ 57.49
PSN0304320D	Lenovo Chromebook 300e G2 AST Daughterboard CBP: DAU-SNG-7909-1 AG Parts: 5C50Y97712 MPN: 5C50Y97712	\$ 13.74
PSN03043210	Lenovo Chromebook 300e G2 AST Touchpad CBP: TPD-SNG-8363-6 AG Parts: None MPN: SA461D-20H3, ST50593092	\$ 17.49
PSN03043212	Lenovo Chromebook 300e G2 AST Wifi Card. Compatible with 100e G2 AST, 300e G2 AST, 14E touch & non-touch, Ideapad 3 CB-11AST05 and S345-14. CBP WIF-SNG-4369-3 AG Parts: 01AX713	\$ 6.24
PSN03043213	Lenovo Chromebook 300e Gen 2 AST Speakers SPK-SET-7979-3 MPN: 5SB0T45109	\$ 12.49
PSN03043215	Lenovo Chromebook 300e Gen 2 AST World Facing Camera. MPN: 5C21A39912	\$ 23.74
PSN0304322A	Lenovo Chromebook 300e Gen 2 AST Motherboard without World facing Camera Port MOT-SNG-3640-1 MPN: 5B20Y97709	\$ 87.49
PSN03043234	Lenovo 11" Chromebook 300e Gen 2 AST Bottom CBP: BOT-SNG-5561-1 AG Parts: 5CB0Y97711 MPN: 5CB0Y97711	\$ 27.24
PSN03043247	Lenovo 11" Chromebook 300e Gen 2 AST Battery Grade B CBP: BAT-SNG-6147-2 AG Parts: 5B10X65680 MPN: 5B10X65680	\$ 57.43
PSN03043248	Lenovo 11" Chromebook 300e Gen 2 AST Battery. Battery Health Less than 80%. or Damaged	\$ 57.43
PSN03044206	Lenovo Chromebook 300e G2 AST Palmrest without world facing camera port AG Parts: 5CB0Z21541 MPN : 5CB0Z21541	\$ 48.74
PSN0304423C	Whole units used for Break Down.	\$ -

PSN03045106	Lenovo 11' Chromebook 300e Gen 2 Intel (WFC) Palmrest PLM-ASY-5371-1	\$ 86.23
PSN04012101	Asus 11" Chromebook C204E Top	\$ 41.19
PSN04012102	Asus 11" Chromebook C204E LCD	\$ 43.31
PSN04012105	Asus 11" Chromebook C204E Bezel CBP: BEZ-SNG-1074-1 AG: 90NX02A1-R7B000	\$ 12.31
PSN04012106	Asus 11" Chromebook C204E Palmrest	\$ 54.94
PSN04012107	Asus 11" Chromebook C204E Bottom	\$ 12.86
PSN0401210A	Asus 11" Chromebook C204E Battery CBP: BAT-SNG-5074-1 AG: 0B200-03370200	\$ 64.56
PSN0401210D	Asus 11" Chromebook C204E Daughterboard	\$ 6.81
PSN04012110	Asus 11" Chromebook C204E Touchpad	\$ 38.44
PSN04012111	Asus 11" Chromebook C204E Hinges	\$ 14.99
PSN04012114	Asus 11" Chromebook C204E Web Camera	\$ 6.81
PSN04012116	Asus 11" Chromebook C204E LCD Cable	\$ 12.31
PSN0401212D	Asus 11" Chromebook C204E Charger	\$ 38.44
PSN04012142	Asus 11" Chromebook C204E Left Hinge	\$ 6.81
PSN04012143	Asus 11" Chromebook C204E Right Hinge	\$ 6.81
TSN020B1001	HP 11" Chromebook G6EE (X-Generic) Top Plate (CBP) BAC-SNG-6851-1	\$ 37.06
TSN020B1005	HP 11" Chromebook G6EE (X-Generic) Bezel (CBP) BEZ-SNG-4231-1	\$ 27.44
TSN020B1010	HP 11" Chromebook G6EE (X-Generic) Touchpad (CBP) TPD-SNG-3415-1	\$ 11.19
TSN020B1016	HP 11" Chromebook G6EE (X-Generic) LCD Cable (CBP) CBL-LCD-1107-2	\$ 9.56
TSN020B101C	HP 11" Chromebook G6EE (X-Genric) Camera Cable (CBP) CBL-CAM-472-1	\$ 13.69
TSN020B3106	HP 11" Chromebook G6EE Intel Palmrest (CBP) PLM-ASY-2810-1	\$ 68.68
TSN020B3109	HP 11" Chromebook G6EE Intel Non-tch Motherboard (CBP) MOT-SNG-9541-1	\$ 178.68
TSN020B5209	HP 11" Chromebook G6EE AMD Motherboard CBP: MOT-SNG-2941-2	\$ 178.68